

Image Processing

Image Filters: Part 1

This technical document introduces the idea of image processing from the basics. The topic covered in this document is image filters, which aids in achieving a stable image. Image filters can also bring out details that may help make the inspection easier and more robust.

1. Image filter effects

Various types of image filters are available to meet the needs of different applications. To successfully stabilise inspections, it is important to be familiar with the different types of filters and their effects on an image.

■ Inspection of foreign particles on mesh

Ignore the gridline caused by the mesh and only bring out the thing flaw




Original image




After image filter

■ Emphasis of PCB components

Increase contrast and emphasise edges of the components mounted on PCB for presence/absence inspection




Original image




After image filter

■ Inspection of foreign particles in a cup

Detect any foreign particles inside the cup while ignoring the contour of the cup and the shape of the cup against the background



Original image



After image filter

■ Inspection of cylindrical metal part

Ignore uneven lighting and texture on the surface and bring out the defect



Original image



After image filter

2. Image filter basics

This section explains four types of image filters that are most commonly used. A 3 x 3 pixel array is used to find the value of the centre pixel and is applied to every pixel in the image.

3 x 3 pixel array

2	5	9
4	7	3
0	1	2

Example of original image

Image



Principle of a 3 x 3 pixel

Filtered image

Expansion filter

In this filtering process, the centre pixel of the 3 x 3 pixel array becomes the maximum value found within the array. The expansion filter is effective in removing dark noise.

2	5	9
4	9	3
0	1	2

Maximum density value



Shrink filter

In this filtering process, the centre pixel of the 3 x 3 pixel array becomes the minimum value found within the array. This filter is effective at enhancing black pixels.

2	5	9
4	0	3
0	1	2

Minimum density value



Averaging filter

In this filtering process, the centre pixel of the 3 x 3 array is replaced with the average value of the array. This filter is effective at reducing noise and adds blur to the image.

2	5	9
4	3	3
0	1	2



Median filter

In this filtering process, the centre pixel of the 3 x 3 array is replaced with the median value of the array. This filter is effective at reducing noise and adds blur to the image.

2	5	9
4	3	3
0	1	2

Median value




Filtering needs are different for every application, but having an understanding of how these image filters work can be advantageous.


\ Filtering Tips / Filtering techniques

Example 1 Outline smoothing Expand and shrink

By applying expand and shrink the same number of times, it can remove the burr on the edge while leaving the original shape of the target.



Original image



Filtered image

3. Edge extraction filters

Edge extraction filters are useful for bringing out the edge when the details of the edge are low. There are numerous edge extraction and enhancement filters which can help increase the contrast of an edge. Each type of filter has different benefits.



Original image

[Sobel and Prewitt filters]

Both the Sobel and Prewitt filters work by extracting edges by separately filtering in the X (horizontal) and Y (vertical) directions, then combining the two results.

A 3 x 3 central pixel is replaced with the combined density value after multiplying each of the nine pixels by a set coefficient. The Sobel filter is better at enhancing edges with less contrast than the Prewitt filter, because the pixel at the centre is multiplied by 2. Although these filters are good at extracting edges, unwanted noise may also be enhanced.

Sobel filter

$$\begin{bmatrix} -1 & -2 & -1 \\ 0 & 0 & 0 \\ 1 & 2 & 1 \end{bmatrix} + \begin{bmatrix} -1 & 0 & 1 \\ -2 & 0 & 2 \\ 1 & 0 & 1 \end{bmatrix}$$



Prewitt filter

$$\begin{bmatrix} -1 & -1 & -1 \\ 0 & 0 & 0 \\ 1 & 1 & 1 \end{bmatrix} + \begin{bmatrix} -1 & 0 & 1 \\ -1 & 0 & 1 \\ -1 & 0 & 1 \end{bmatrix}$$



■ Edge-extraction filter in a specified direction

Some edge extraction filters can be applied in just the X or Y direction. This can help bring out flaws that occur in a certain direction.

Sobel in X

$$\begin{bmatrix} -1 & 0 & 1 \\ -2 & 0 & 2 \\ -1 & 0 & 1 \end{bmatrix}$$



Sobel in Y

$$\begin{bmatrix} -1 & -2 & -1 \\ 0 & 0 & 0 \\ 1 & 2 & 1 \end{bmatrix}$$



[Edge extraction filters]

	Derivation	Horizontal direction	Vertical direction	Diagonal	Others
Prewitt filter	Firstderivation	○	○	△	
Sobel filter	Firstderivation	◎	◎	○	
Roberts filter	Firstderivation	△	△	○	
Laplacian filter	Second derivation	△	△	△	Direction-independent


Symbols: ◎=best ○=good △=fair

\ Filtering Tips / Technique for using image filters


Example 2 Emphasis of small surface flaws

Sobel filter + binary conversion + expansion

Flaws are enhanced while minimising noise



Original image



Sobel filter




Binary conversion + expansion


Example 3 Stable measurement by noise reduction

Averaging and median

By applying the averaging and median filter together, the surface roughness is minimised for stable measurement




Original image



Average + median filter

Waveforms of edge strength



■ An introduction to lineup of image processing

XG-8000 / XG-7000 Series

Best solution meeting every need

All of lineup of cameras including line scan cameras, high speed using distributed processing on multicore DSP, a wide variety of flexible inspection tools, interface that allows users to create on their own make a precise response to customers' needs.



CV-X100 Series

Offering tools having the same ability to judge as the judgement of human. Anyone can use it easily.


The "Auto-teach inspection tool" which recognises those items that are different from conforming items as non-conforming items is incorporated into the series. This tool allows human-like inspection. This series can be globally deployed and used by anyone by setting and operating by just selecting and clicking.



■ Lineup of lights that support a wide range of inspections



Direct ring light



Multi-angle round light



Multi-angle square light



Bar light




Dome light



Backlight



Coaxial light




Spot light



Low angle light



Square bar light



Line light



Controller for LED light

■ Lineup of lenses that can be selected based on the camera types and accuracy requirements



Super high resolution/low distortion lenses




High resolution/low distortion lenses




CCTV lenses



Macro lens



Compact camera lenses



Line scan camera lenses

KEYENCE

Please visit: www.keyence.com

KEYENCE CORPORATION

1-3-14, Higashi-Nakajima, Higashi-Yodogawa-ku, Osaka, 533-8555, Japan Phone: +81-6-6379-2211

AUSTRIA
Phone: +43 22 36-3782 66-0 Fax: +43 22 36-3782 66-30

BELGIUM
Phone: +32 1 528 1222 Fax: +32 1 520 1623

BRAZIL
Phone: +55-11-3045-4011 Fax: +55-11-3045-5219

CANADA
Phone: +1-905-366-7655 Fax: +1-905-366-1122

CHINA
Phone: +86-21-68757500 Fax: +86-21-68757550

CZECH REPUBLIC
Phone: +420 222 191 483 Fax: +420 222 191 505

FRANCE
Phone: +33 1 56 37 78 00 Fax: +33 1 56 37 78 01

GERMANY
Phone: +49 61 02 36 89-0 Fax: +49 61 02 36 89-100

HONG KONG
Phone: +852-3104-1010 Fax: +852-3104-1080

HUNGARY
Phone: +36 1 802 73 60 Fax: +36 1 802 73 61

INDIA
Phone: +91-44-4963-0900 Fax: +91-44-4963-0901

ITALY
Phone: +39-02-6688220 Fax: +39-02-66825099

JAPAN
Phone: +81-6-6379-2211 Fax: +81-6-6379-2131

KOREA
Phone: +82-31-789-4300 Fax: +82-31-789-4301

MALAYSIA
Phone: +60-3-2092-2211 Fax: +60-3-2092-2131

MEXICO
Phone: +52-81-8220-7900 Fax: +52-81-8220-9097

NETHERLANDS
Phone: +31 40 20 66 100 Fax: +31 40 20 66 112

POLAND
Phone: +48 71 36861 60 Fax: +48 71 36861 62

ROMANIA
Phone: +40 269-232-808 Fax: +40 269-232-808

SINGAPORE
Phone: +65-6392-1011 Fax: +65-6392-5055

SLOVAKIA
Phone: +421 2 5939 6461 Fax: +421 2 5939 6200



SAFETY INFORMATION

Please read the instruction manual carefully in order to safely operate any KEYENCE product.

